Chemical Process Equipment

GENERAL

- 1. When ordering spare parts, the serial number, type of filter, drawing number and item (pos.) number should be indicated. For example: Paddle filter RPD 8-514-89 Pos. 401 cylinder.
- 2. It is advisable to carry some important wear parts in stock. On request, we will be glad to submit a corresponding offer.
- 3. The Rosenmund filter is generally maintenance-free but the following items require regular attention:
 - a) For vessels with mainbody flange, it is important to retighten all bolts on the bodyflange during the first three months of operation to account for hardware "relaxation" in thermal cycling etc.
 It is recommended to tighten bolts in a standard schedule. Non-compliance with recommendation can result in leaking
 - gasket or blow -out.
 b) Lubricate the guide tubes and bearings once per months by applying grease to the nipples. See lubrication plan later in this section.
 - c) Inspect packings on shafts inside filter every 6 months.
 - d) Inspect packing around discharge chute every 6 months.
 - e) Inspect o-ring and scraper under liquid tight cover every 6 months.
 - f) Inspect packing around main shaft where it enters the dished head.
 - g) Check oil level in gearbox once every 6 months and top up as necessary.

 Change oil as per the information and schedule as given in the section on the gearbox.
 - h) Replace oil in hydraulic unit every 12 months. (Replace oil filters when changing oil.
 - i) Check oil in "Voith" turbo coupling every 12 months and change oil as schedule and instruction given later in this section. (where installed)

ROSENMUND INC.

Chemical Process Equipment

j) Lubricate the chain drive as per the instruction given later in the section using the recommended lubricants.

(where installed)

For service, call Rosenmund inc. service department, (704)398-1111

Fax (704) 398-1089